

Klemme	Ausgang	LED	Next = Hp0				Next = Hp1				Next = Hp2			
			Hp0	Hp1	Sh1	Hp2	Hp0	Hp1	Sh1	Hp2	Hp0	Hp1	Sh1	Hp2
Taste	IB		1	2	3	4	1	2	3	4	1	2	3	4
Index			0	1	2	3	4	5	6	7	8	9	10	11

12	8	Vs Gelb oben	0	1	0	1	0	0	0	0	0	0	0	0	128
11			0	1	0	1	0	0	0	0	0	1	0	1	64
10	7	Vs Gelb unten	0	0	0	0	0	1	0	1	0	1	0	1	32
9	6	Vs Grün oben	0	0	0	0	0	1	0	1	0	0	0	0	16
8			0	0	0	0	0	0	1	0	0	0	0	0	8
7	5	Vs Grün unten	0	0	0	0	0	0	1	0	0	0	0	0	4
6	4	Hs Weiß	0	0	1	0	0	0	1	0	0	1	0	0	2
5			0	0	0	0	0	0	0	0	0	0	0	0	1
4	3	Hs Gelb	0	0	0	1	0	0	0	1	0	0	1	0	1
3	2	Hs Grün	0	1	0	1	0	1	0	1	0	1	0	1	1
2			1	0	0	0	1	0	0	0	1	0	0	0	1
1	1	Hs Rot rechts	CV 561	CV 563	CV 565	CV 567	CV 569	CV 571	CV 573	CV 575	CV 577	CV 579	CV 581	CV 583	
Wert			1	194	8	198	1	50	8	54	1	98	8	102	

CV 513 Adresse dieses Signaldekoders

CV 515	0
CV 516	0
CV 517	0
CV 518	0
CV 545	4
CV 548	40
CV 549	255
CV 550	0
CV 551	4
CV 552	8

CV 559 CV 513 des nächsten Signaldekoders